

ABB solar inverters

Product manual Aurora Manager LITE



IMPORTANT SAFETY INSTRUCTIONS



Operators must read this manual and follow its instructions strictly, as ABB will not accept responsibility for damage caused to individuals and/or goods, or suffered by the equipment, if the conditions described below are not complied with.

Product Manual

Aurora Manager LITE - Advanced configuration software

1 - Introduction and general information



2 - Specifications



3 - Guide to using the software



4 - Description of the menus



5 - Inverter working area



Document and intended readers

Scope and structure of the document

This user manual constitutes a valid guide which permits advanced configuration of the ABB inverters to optimize their operation.



The main language in which the document has been written is ITALIAN; however, in the case of any inconsistencies or doubts ask the manufacturer for the original document.

Characteristics of the personnel



The Customer must ensure that the operator has the expertise and the training necessary to fulfill their duties. Personnel responsible for the use or maintenance of the equipment must be expert, knowledgeable, and mature enough for the tasks described and must be able to be relied upon to interpret that described in the manual correctly.

Contents

Introduction and general information	4
Document and intended readers	4
Scope and structure of the document	4
Characteristics of the personnel	4
Contents	5
Field of use, general conditions	7
Specified or permitted use	7
Limits of the field of use	7
Improper or unauthorized use	7
Characteristics	8
General conditions	8
Description of the Aurora Manager LITE software	9
Structure of the software interface	10
1. Menu bar	10
2. Tree diagram of the system	10
3. Inverter working area	11
4. RS485 bus update key	11
5. Information bar	11
Structure of Aurora Manager LITE	12
Structure of the menus.....	12
Structure of the work area.....	13
Guide to using the software	17
Checking the communication	17
Checking the COM port associated with the signal converter	17
Analogic inputs configuration procedure	18
String monitoring configuration procedure	18
Inverter firmware updating procedure	18
Description of the menus	19
"Communication" menu	19
COM Setting:	19
Unit Scan setting:	20
"Program" menu	21
"Configuration" menu	23
Assign RS485 address:	23
Setup area access:	24
"Window" menu	25
"Help" menu	25
About this:	25
Aurora Service:	25
Inverter working area	26
"Unit ID" tab	27
"Monitoring" tab	28





"Partner Devices" tab	31
"Partner ID" tab (display board)	31
"Partner ID" tab (Communication board).....	31
"States" tab (Communication board)	32
"Measurements" tab (Communication board)	32
"Analog Input Settings" tab (Communication board).....	33
"Partner ID" tab (Fuse Control Board)	33
"States" tab (Fuse Control Board)	34
"Measures" tab (Fuse Control Board).....	35
"Parameters" tab (Fuse Control Board)	35
"Global Settings" tab (Fuse Control Board).....	36
"Strings setting" tab (Fuse Control Board).....	37
"Partner ID" tab (wi-fi board).....	39
"Partner ID" tab (Ethernet board).....	39
"Partner ID" tab (PMU board)	40
"States" tab (PMU board).....	40
"Measures" tab (PMU board).....	40
"Analogic inputs settings" (PMU board).....	41
"Aux RS485" tab (PMU board)	42
"PMU" tab (PMU board).....	42
"Data logger" tab	46
"Event log" tab	46
"Alarms & warnings" tab	47
"Variables" tab	47
"Setup" tab	48
"DC side" tab:	48
"AC side" tab:.....	49
Grid connection	49
Grid protection	50
High frequency derating	51
Vgrid rise suppression (Max AVG grid)	52
Anti Islanding	52
LVRT/HVRT-LFRT/HFRT	54
"Special Function" tab	55
"Ground Fault Interface" tab	56
"Clock" tab	57
"Digital input" tab.....	57
"Digital output" tab.....	58
"Serial Link" tab.....	59
"Night Startup Mode" tab	59
"Power Reduction" tab	60
"Reactive Power Regulation" tab	61
"Select regulation mode" tab	62
"Cos-phi f(P) curve setup" tab	63
"Q(U) curve set-up"	64
Further information	65
Contact us	66

Field of use, general conditions

ABB does not accept any responsibility for damage of any kind that may be caused by incorrect or careless operations.



Use of the software for any purpose that does not conform to that specified in the field of use is prohibited. The software MUST NOT be used by inexperienced personnel, or personnel who are experienced but perform operations on the equipment which are not in accordance with that described in this manual and in the documentation attached.



Specified or permitted use

Aurora Manager LITE is technical software used for the following operations:

- Monitoring
- Advanced configuration
- Updating of the firmware of the ABB inverters.

Limits of the field of use

Aurora Manager LITE can be used on the operating systems Windows XP, 7, 8 (framework .NET version 4.0 or later).

The installation and running of Aurora Manager Lite is only permitted if you have administrator rights.

Aurora Manager LITE CAN be used with 32 bit and 64 bit operating systems.

This manual is applicable for Aurora Manager LITE version 5.0.0.56 or later.

Aurora Manager LITE can be used linked to the following inverters:

UNO-2.0/2.5-I-OUTD

UNO-2.0/3.0/3.6/4.2-TL-OUTD

TRIO-5.8/7.5/8.5-TL-OUTD

PVI-10.0/12.5-TL-OUTD

TRIO-20.0/27.6-TL-OUTD

TRIO-50.0-TL-OUTD

CORE

PLUS-PLUS -(HV). (firmware updating only)

Access to the INSTALLER level which permits advanced configuration of the inverter is password-protected.

Improper or unauthorized use

IT IS STRICTLY PROHIBITED:

- *To use Aurora Manager LITE without having read and understood the content of the user manual correctly.*
- *To use the software to change internal parameters of the inverter which may render it NOT IN CONFORMITY with the regulations in force in the country of installation.*

General conditions

A description of the equipment characteristics is provided to identify its main components and specify the technical terminology used in the manual.

This chapter contains information about the models, details of the equipment, characteristics and technical data, overall dimensions and equipment identification.



The customer/Installer takes full responsibility if, when reading this manual, the chronological order of its presentation provided is not observed. All information is provided considering occasional inclusion of information in previous chapters.



In certain cases, there may be a need to separately document software functionality or attach supplementary documentation to this manual which is intended for more qualified professionals.

Description of the Aurora Manager LITE software

For the characteristics and functions that Aurora Manager LITE makes available is indicated for:

1. Local monitoring of the inverter.

It is possible to monitor the main parameters relating to:

General state

Statistical data relating to the production of energy

Input and output values

Internal temperature

Values relating to the insulation of the photovoltaic generator

Date and time



2. Advanced configuration of the inverter (INSTALLER access level):

Offers the option of applying advanced settings for the inverter. Access to this section of the software is password protected as it permits the modification of sensitive parameters such as those relating to the standard for connection to the grid in force in the country of installation.

The password can be obtained by registering on the site <https://registration.abbsolarinverters.com/>


3. Updating of the inverter firmware.

Updating the inverter Firmware is process which may become necessary to improve the performance of the inverter or increase its functions.

In order to use the software a connection must be established between the PC and the inverter (by means of an RS485 communication line) using a PVI-USB-RS485_232 signal converter.


In all cases, the use of ABB products is recommended to avoid problems of incompatibility with the inverter.

Structure of the software interface




1. Menu bar

Contains the menus by means of which the functions of the Software can be accessed.



2. Tree diagram of the system


This section shows all the inverters connected to the RS485 line and identified during the scanning process. The inverters are arranged and displayed based on their Serial Number.



For the centralized inverters, the internal components of the inverter will also be displayed.

3. Inverter working area

When an inverter shown in the tree diagram of the system is selected, the multitab structure of the program which permits configuration of the inverter is displayed. Depending on the access level (USER or INSTALLER), the configuration option and therefore also the displaying of the work area will be different.



4. RS485 bus update key

Permits scanning of the inverters connected to the RS485 bus.



5. Information bar

Contains the values of the settings made relating to the Communication menu.



Structure of Aurora Manager LITE

Structure of the menus



Menu	Submenu	Command/Option	Description
Communication	COM Setting	COM Port to use	Selection of the COM port used for communication
		Baud Rate	Speed of the communication (19200bps)
	Unit Scan setting	▶	Possibility of limiting the number of addresses in the RS485 bus scanning phase
Program	Device update	▶	Updating of the inverter Firmware using the .tib file
Configuration	Assign RS485 addresses	▶	Possibility of automatic (or personalized) assigning of the addresses of the inverters connected to the RS485 bus
	Setup Area Access	▶	Selection of the access level. The personal information and the password obtained by registering on the site https://registration.abbsolarinverters.com/ are requested
Window	Restore default window	▶	Resizing of the window
Help	About this...	▶	Information about the version of the Aurora Manager LITE Software
	Aurora Service	▶	ABB Service contacts
Exit		▶	Closing of the program

Structure of the work area



TAB	Level 1 TAB.	Level 2 TAB.	Command/Option	Description
Unit ID	▶	▶	▶	Inverter identification information (FW version, Device info, Manufacturing info, Device settings)
Monitoring	▶	▶	▶	Acquisition of the inverter input and output data in real time
Partner Devices	Display	Partner ID	▶	"Display" board identification information (S/N, P/N, WK, etc.)
	Communication board	Partner ID	▶	"Communication" board identification information (S/N, P/N, WK, etc.)
		States	▶	State of the devices monitored by the "Communication" board
		Measures	▶	Acquisition of the "Communication" board data in real time
		Analogic Input Settings	▶	Settings of the analogic inputs
	Fuse control board	Partner ID	▶	"Fuse control" board identification information (S/N, P/N, WK, etc.)
		States	▶	State of the devices monitored by the "Fuse control" board
		Measures	▶	Acquisition of the "Fuse control" board data in real time
		Parameters	▶	Copies the input configuration to the whole chain or to selected inverters by means of the dedicated 485 address.
		Global Settings	▶	Setting of the common parameters for monitoring the strings (overcurrent, minimum average current for unbalanced current alarm, etc.)
		Strings Settings	▶	Setting of the monitoring of the strings (string current weight, tolerance, string current control enable/disable, etc.)
	PMU board	Partner ID	▶	"Service board" identification information (S/N, P/N, WK, etc.)
		States	▶	State of the devices monitored by the "Service board"
		Measures	▶	Acquisition of the "Service board" data in real time
		Analogic inputs settings	▶	Setting of the "Service board" analogic inputs
		Aux RS_485	▶	Settings of the communication protocol and baud rate
		PMU	▶	Settings of the active and reactive power management modes
Ethernet board	Partner ID	▶	"Ethernet board" identification information (S/N, P/N, WK, etc.)	
Wi-fi board	Partner ID	▶	"Wi-Fi board" identification information (S/N, P/N, WK, etc.)	
Data logger	▶	▶	▶	Acquisition of the system data in real time
Event log	Alarms & Warnings	▶	▶	Reading and downloading of the alarms and warnings log
	Variables	▶	▶	Reading and downloading of the variables log

TAB	Level 1 TAB.	Level 2 TAB.	Command/Option	Description		
Setup	DC Side	▶	Vstart1	Setting of the value of the activation voltage of channel 1		
		▶	Vstart2	Setting of the value of the activation voltage of channel 2		
		▶	TprotUV	Setting of the duration of intervention of the UnderVoltage protection (time during which the inverter remains connected to the grid following the detection of an input UV)		
		▶	MPPT Scanning	Possibility of activating/deactivating the MPPT scanning function and setting the time interval between scans		
		▶	MPPT Noise Amplitude	possibility of modifying the MPPT noise amplitude		
	AC Side	Grid connection (parameters which define the possibility of the inverter connecting to the grid)		Max grid voltage for connection	Maximum permitted grid voltage allowing connection to the grid	
				Min grid voltage for connection	Minimum permitted grid voltage allowing connection to the grid	
				Max grid frequency for connection	Maximum permitted grid frequency allowing connection to the grid	
				Min grid frequency for connection	Minimum permitted grid frequency allowing connection to the grid	
				Check time before connection or after generic fault	Time at which the inverter performs the checks of the grid before connection to the grid as first connection or after a generic fault (not a grid fault)	
				Check time before connection after grid fault	Time at which the inverter performs the checks of the grid before connection to the grid after a fault of one of the grid parameters	
				Slow ramp enable/disable	Enables/disables the ramp for admission of power to the grid	
				Ramp Slope [%Pn/min]	Slope of the ramp for admission of power to the grid	
				Ramp Slope fault [%Pn/min]	Slope of the ramp for admission of power to the grid after disconnection due to a fault	
			Grid protection (parameters which define the possibility of disconnection of the inverter from the grid)	U>> Maximum grid voltage		Protection enabling/disabling
					Protection threshold value	
					Duration of intervention of the protection	
		U> Maximum grid voltage			Protection enabling/disabling	
					Protection threshold value	
					Duration of intervention of the protection	
		U< Minimum grid voltage			Protection enabling/disabling	
					Protection threshold value	
					Duration of intervention of the protection	
		U<< Minimum grid voltage			Protection enabling/disabling	
					Protection threshold value	
					Duration of intervention of the protection	
		U<<< Minimum grid voltage			Protection enabling/disabling	
				Protection threshold value		
	Duration of intervention of the protection					
F>> Maximum grid frequency		Protection enabling/disabling				
		Protection threshold value				
		Duration of intervention of the protection				
F> Maximum grid frequency		Protection enabling/disabling				
		Protection threshold value				
		Duration of intervention of the protection				
F< Minimum grid frequency		Protection enabling/disabling				
		Protection threshold value				
		Duration of intervention of the protection				
F<< Minimum grid frequency		Protection enabling/disabling				
		Protection threshold value				
		Duration of intervention of the protection				
	K LVRT	Low voltage ride-through coefficient, regulates the reactive current during a grid dip				



TAB	Level 1 TAB.	Level 2 TAB.	Command/Option	Description		
Setup	AC side	High frequency derating	Frequency threshold for power derating start	Limit frequency value for starting derating		
			Frequency threshold for derating stop	Limit frequency value for stopping derating		
			(reduction of the active power admitted to the grid due to high grid frequency)	Power/frequency slew rate	Slew (W/Hz) for limiting the active power due to a high grid frequency	
				Restore time after OF derating	Time necessary to restore normal operation of the inverter after the frequency has returned to within the range	
				Derating Mode	Disabled	
					BDEW mode	
					VDE AR-N mode	
		CEI 0-21 mode				
		Intentional delay time	Setting of the delay starting frequency derating			
		Release ramp EN/DIS	Enables/disables the ramp for admission of power to the grid			
		Vgrid rise suppression (max AVG Vgrid)	Protection enable/disable	Enables/disables the disconnection of the grid if the average grid voltage value exceeds the limit set		
				Derating enable/disable	Enables/disables the derating of the active power to prevent the average grid voltage from exceeding the threshold value set and causing disconnection of the inverter from the grid.	
			(protection/derating due to high average grid voltage values)	Protection threshold	Threshold value of the average voltage overvoltage protection	
				Anti Islanding	Active A.I.	Enables/disables the islanding protection (active)
					Active A.I. freq drift	Enables/disables the checking of the grid by means of a frequency chirp
		Passive A.I.	Enables/disables the islanding protection (passive)			
		Passive A.I. Δt	Checks the passive protection at a given time			
		Passive A.I. DEG	Checks the passive protection for an grid frequency amplitude			
		LVRT/HVRT LFRT/HFRT	▶	Low voltage ride-through coefficient, regulates the reactive current during a grid dip		
		Special functions	▶	Remote On/Off contact management (ext command)	Enables/disables the switching off of the inverter by of the remote ON/OFF signal	
				Reset mode	Manual unlocking in the event of errors linked with the grid parameters (for the Japanese grid standard)	
	Radio frequency Inj			Sets a frequency interval for any conveyed wave signals, which the inverter must not identify as grid errors		
	Digital alarm cont.			Sets the configuration of the alarm contact		
	Ground Fault Interface	▶	Minimum R_iso	Setting of the R_iso limit value allowing connection to the grid		
			Minimum time for R_iso check	Setting of the insulation resistance (R-iso) measurement time		
	Clock	▶	▶	Inverter data and time settings		
	Digital input	▶	User Inputs	Setting of the digital input contacts		
	Digital output	▶	User Outputs	Setting of the digital output contacts		
	Serial Links	▶	User links	Settings of the communication protocol, RS485 line serial address, baud rate		
	Night startup mode	▶	Night mode EN/DIS	Enables/disables night operation		
			Max Vin for connection	Sets the max input voltage allowing connection of the inverter		
			Min Vbulk for connection	Sets the min bulk voltage allowing connection of the inverter		
			Check for connection timeout	Sets the waiting time before connection to the grid		

TAB	Level 1 TAB.	Level 2 TAB.	Command/Option	Description	
Power reduction	User power reduction	Actual max power value percent	▶	percentage limitation of power set leaving the inverter	
		New max power percent	▶	new percentage power limitation value set leaving the inverter	
		Smooth time [s]	Slope mode		fixes the slope of the ramp, time necessary to range from 0 to 100% of the Pmax
			Trip-time mode		Time necessary to pass from the current Pout to the new power value set
	P. limits	P regulation max value [W]	▶	limitation of power leaving the inverter	
		P regulation value at cos-phi=0.9 [W]	▶	limitation of power leaving the inverter at cos-phi 0.9	
		Smax [VA]	▶	Maximum apparent power	
		P regulation MIN smooth time [s]	▶	Minimum power regulation for smooth time	
	Reactive Power Regulation	Select regulation mode	Regulation mode	No regulation	No regulation of the reactive power
				cos(phi) fixed	Setting of the power factor to a fixed value
Q fixed				Setting of Tan-phi (Q/P) to a fixed value	
cos(phi)=f(P)				Power factor as a function of the active power supplied by the inverter	
Q(U)				Reactive power as a function of the grid voltage measures by the inverter	
cos(phi)=f(P) curve set-up		▶	cos(phi)=f(P) characteristic construction (4 points)	Setting of the 4 values of P/Pn% and of the relative values of cos-phi necessary to create the curve of admission of reactive power required	
			Lock-in/lock-out voltage thresholds enable/disable	Enabling/disabling of the lock-in/lock-out voltage thresholds	
			Lock-in/lock-out voltage thresholds setting	Setting of the lock-in and lock-out voltage thresholds	
			Check and graph my table	Displaying of the cos(phi)=f(P) curve created by setting the values of P/Pn% and relative cos-phi	
			Read table from device	Reading of the cos(phi)=f(P) curve set on the inverter	
			Restore default curve	Restoring of the original cos(phi)=f(P) curve	
			Write my table on device	Memorization of the cos(phi)=f(P) curve in the inverter	
			Q(U) curve set-up	▶	Q(U) characteristic construction (4 points)
Lock-in/lock-out active power thresholds en/dis		Enabling/disabling of the lock-in/lock-out voltage thresholds			
Lock-in/lock-out active power thresholds setting		Setting of the lock-in and lock-out voltage thresholds			
Check and graph my table		Displaying of the Q=f(U) curve created by setting the values of P/Pn% and relative cos-phi			
Read table from device		Reading of the Q=f(U) curve set on the inverter			
Restore default curve		Restoring of the original Q=f(U) curve			
Write my table on device		Memorization of the Q=f(U) curve in the inverter			

The sections (TABs) highlighted in grey, relating to the advanced configuration of the inverter (INSTALLER access level), are only available by logging in on the menu "Configuration > Setup Area access".



Guide to using the software

3

Checking the communication

- 1 - Connect the inverter to the signal converter (refer to the instructions given in the product manual)
- 2 - Connect the converter to the PC


To check with which COM port the converter has been associated, refer to the procedure "Checking the COM port associated with the signal converter" in this manual

- 3 - Open the Aurora Manager LITE software
- 4 - Apply the communication configuration settings (refer to the Communication Menu paragraph in this manual)
- 5 - Scan the RS485 bus (using the refresh button)
- 6 - Check the functions available on the Unit ID and Monitoring tabs (refer to the paragraph relating to the Unit ID tab and the Monitoring tab in this manual)


Checking the COM port associated with the signal converter

- 1 - From START, go to the "Control panel"
- 2 - Select "Device management"
- 3 - Select "Ports (COM and LPT)"
- 4 - Check "Communication port (COM)"

Next to the port selected is indicated the name of the COM (in the example COM4) that must be selected in the Aurora Manager Software communication settings.



- 5 - Double-clicking on the USB port takes you to the port properties screen. On the "general" tab, check that the manufacturer is FTDI.



Analogic inputs configuration procedure

- 1 - Follow the procedure for "Checking the communication"
- 2 - Apply the settings relating to the ANALOGIC INPUTS (refer to the "Partner devices - Communication Board" tab in this manual)

String monitoring configuration procedure

- 1 - Follow the procedure for "Checking the communication"
- 2 - Apply the settings relating to the STRING MONITORING (refer to the "Partner devices - Fuse Control Board" tab - "Global settings" tab)

Inverter firmware updating procedure


- 1 - Carry out the procedure for "Checking the communication"
- 2 - Check that you have the .tib file containing the new FW to be installed on the inverter
- 3 - Follow the instructions given in the paragraph relating to the "Program" menu in this manual

Description of the menus


4

"Communication" menu

Used to configure the parameters relating to the communication with the inverters connected to the RS485 bus.




The Communication menu consists of two submenus:




COM Setting:

Used to select the COM port to which the converter being used for communication with the unit(s) is connected and the baud rate (speed of communication of the devices on the RS485 bus).

To identify the COM port to which the converter is connected, follow the dedicated procedure (Checking the COM port associated with the signal converter). The baud rate must be set at 19200.




The maximum scanning address that has been set is displayed on the information bar (at the bottom left):



Unit Scan setting:


Used to set a limit for the number of addresses that the Software scans during use. The default value set is 64 (maximum value that can be set on the inverters), so the software scans the entire RS485 bus.

E.g. if the communication line consists of 5 inverters to which have been assigned (from the display) the addresses 2, 3, 4, 5, 6, in this section "6" can be set to limit the time required for scanning.



"Program" menu


This section of the program permits updating of the inverter Firmware.



Updating the inverter Firmware is process which may become necessary to improve the performance of the inverter or increase its functions. Updating the Firmware requires the availability of the Firmware package with which to carry out the update itself: this can be downloaded from the site <https://registration.abbsolarinverters.com/> or requested from ABB Service and is issued as a .tib file, to be used directly via Aurora Manager LITE in accordance with the instructions described below.

Disconnect the inverter from the grid before reprogramming the firmware. This can be done using Aurora Manager Lite on the tab Setup> Special Function> Remote ON/OFF at OFF and enter SET.


The Program menu consists of a single submenu:




As the first operation, the settings of the "Communication Setup" field must be applied:

Not configurable: the converter used is model PVI-USB-RS485_232.

The Scan all addresses function can be used to select all the inverter addresses during the scan of the RS485 bus (to be carried out during the following steps).



Next the RS485 bus must be scanned to identify the inverters connected, using the "SEARCH RS485 LINE" button



Once the scan is complete, the inverters that require a Firmware update must be selected (by default all inverters detected during the scan are selected). If several inverters are selected, Aurora Manager LITE will program the units selected sequentially

	Prog	Prog. state
7627	<input checked="" type="checkbox"/>	Valid

Select the file containing the new Firmware to be installed using the "Select Update Files" button. The extension of the file to be used should be [.tib]. Once the new Firmware has been uploaded correctly, Aurora Manager will display the following window:


The last operation to be carried out is to confirm the Firmware upgrade using the "START UPDATE" button.

The Firmware upgrade process takes place sequentially for all the inverters that require it based on the Firmware present in the .tib file

The entire reprogramming process takes approximately 20 minutes per inverter

Once the programming is complete, the inverter connects to the grid automatically, resetting the remote OFF command set previously.


The end of the programming phase will be indicated by the following window.




Once the programming phase is complete, a report relating to the outcome of the reprogramming will be generated automatically and filed on C:\Programmi\ABB\Aurora Manager\liteFW_update_reports. To check that the reprogramming has taken place, the UNIT ID > device info > Update version tab will indicate the new file with extension .tib.

"Configuration" menu

Used to assign/change the address of the inverters connected to the RS485 bus.




The Configuration menu consists of two submenus:




Assign RS485 address:



This function is particularly useful if there is a large number of inverters in the RS485 chain as it can be used to assign the RS485 address automatically, therefore without having to interact with the display of each inverter in the system.



By putting a check mark in the search for an individual inverter by serial number and clicking on "UNIT SEARCH", you see in the table the inverter searched for with indication of the S/N of the inverter, the current RS485 address and the new RS485 address that you wish to assign.



For systems consisting of several units, it is possible to scan all the inverters by putting a check mark in "Use Custom Range"




Displaying a table that shows: serial number of the inverters - current address - new address.

The "Assign Address" button can be used to change the 485 addresses, defined in the "New ADDR" field.

For the commissioning phase (all inverters have an address pre-set at 1) Aurora Manager Lite will display a progressive address (editable)

For the maintenance phase (the inverters already have an assigned progressive address) the field "New ADDR" will give the address already set, to be changed manually if necessary.



On completion of the RS485 address assigning procedure, it is advisable to refresh the list of inverters to check that the address has been assigned to each inverter correctly.

Setup area access:

Used to enter the personal data required for access to the INSTALLER level and so unlock the areas of Aurora Manager Lite relating to the advanced configuration of the inverter.

The personal data and the password to be entered are the same as those used when registering on the site <https://registration.abbsolarinverters.com/>

Setup area currently locked (after SW update)

User data

Email address (max 100 characters)

User name (max 50 characters)

User surname (max 50 characters)

User date of birth (DDMMYYYY format)

User password (short)

Password (short)

ENTER

Once the personal data has been entered, press ENTER. Aurora Manager LITE will allow you to carry out the advanced configuration of the inverter.

Setup area unlocked

User data

Email address (max 100 characters)

User name (max 50 characters)


User surname (max 50 characters)

User date of birth (DDMMYYYY format)

To obtain the password, register on the site <https://registration.abbsolarinverters.com/> where, on entering your personal data, you will receive an e-mail with the login details.

"Window" menu

Used to resize the software interface window to the default size.




The Window menu consists of a single submenu:




"Help" menu

Used to obtain the ABB Service contact details and information about the Aurora Manager LITE Software version




The Help menu consists of two submenus:



About this:

Go to the "About This" submenu for information about the Aurora Manager LITE software such as, for example, the Software version



Aurora Service:

Go to the "Aurora Service" submenu for the ABB Service contact details



Inverter working area


5

After having configured the parameters relating to the Communication menu, the RS485 bus can be scanned to search for the inverters connected to it via the PVI-USB-RS485_232 signal converter.


The scan is carried out by clicking on the "REFRESH" button at the bottom left.



Once the scan is complete, the inverters identified are shown in the tree structure of the system.



By selecting one of the inverters, the functions are made available in the work area relating to the inverter.



The default functions of Aurora Manager Lite (gaining access with the USER level) are:

- 1 - Unit ID tab
- 2 - Monitoring tab
- 3 - Partner Devices tab
- 4 - Data Logger tab
- 5 - Event Log tab
- 6 - Setup tab (INSTALLER access level)
- 7 - Power Reduction tab
- 8 - Reactive power regulation tab (some functions active with INSTALLER access)

"Unit ID" tab

Displays the "identity card" of the inverter selected.
 Tabs relating to TRIO-50.0-TL-OUTD string inverter:

DEVICE INFO	
Type	TRIO-50.0-TL-OUTD
Grid Standard	BDEW
Trafo	NO TRAF0
Mode	SOLAR
Nominal Power	50000 W
Output Type	THREE-PHASE
FLASH Version	Z038
FLASH ID	3N63
Update version	1605D

FIRMWARE VERSION	
FW (POW_Booster)	A086
FW (POW_Inverter)	B1B7
FW (POW_Supervisor)	C133

DEVICE SETTINGS	
RS485 Address	1
Input Mode	Single Channel
GND Mode	--

MANUFACTURING INFO	
SN	111111
PN	-3N63-
Week/Year	4915
Trac. ID	010000.0100
SN_DCBOX	666666
PN_DCBOX	-3N83-
Week/Year_DCBOX	4915

Tabs relating to CORE centralized inverter (Power Converter):

DEVICE INFO	
Type	CORE (Pow_Converter)
Grid Standard	CHINA LV
Trafo	NO TRAF0
Mode	SOLAR
Nominal Power	50000 W
FLASH Version	Z033
FLASH ID	V194
Update version	12345

FIRMWARE VERSION	
FW (POW_Inverter)	B038
FW (POW_Supervisor)	e059

DEVICE SETTINGS	
RS485 Address	3
GND Mode	

MANUFACTURING INFO	
SN	30001
PN	-V194-
Week/Year	0115
Trac. ID	010000.0100
RACK SN	10001
RACK PN	-3N31-



Tabs relating to CORE centralized inverter (System Controller):

DEVICE INFO	
Type	CORE (Sys Controller)
FLASH Version	e00C
FLASH ID	V196
Update version	--

FIRMWARE VERSION	
FW (POW_Supervisor)	E001

DEVICE SETTINGS	
RS485 Address	2

MANUFACTURING INFO	
SN	20001
PN	-V19601
Week/Year	0215
Trac. ID	N/A
RACK SN	10001
RACK PN	-3N31-

The information available is divided into 4 categories:

Device Info: General information relating to the inverter.

Manufacturing Info: Inverter identification information.

Device Settings: General information relating to the settings applied on the inverter.


Firmware version: Information relating to the firmware installed on the inverter.

"Monitoring" tab

The displaying of this menu differs depending on the type of inverter to which Aurora Manager Lite is connected:

- 1 - TRIO-50.0-TL string three-phase
- 2 - TRIO-20./27.6-TL string three-phase
- 3 - CORE centralized inverters

1 - Displaying of the TRIO-50.0-TL string inverter instantaneous monitoring data:




The data available relates to:

- "Unit State": General state of the inverter
- "DC side": Input parameters
- "AC side": Output parameters
- "GF Interface": Parameters relating to the insulation of the PV generator
- "Fans": Information about the fans in the inverter (revolutions per minute rpm)
- "Temperature [°C]": Internal temperature of the Inverter
- "Inner Clock": Inverter Date and Time
- Indicators relating to the general state of the inverter (status), to the 485 (RS 485) serial communication and power derating
- Statistical data relating to the production of energy by the inverter

The indicators can assume three different states:

- Green LED indicates correct operation
- Red LED indicates alarm
- Orange LED indicates warning

2 - Displaying of the TRIO-20.0/27.6-TL string inverter instantaneous monitoring data:



The data available relates to:

- "Unit State": General state of the inverter
- "DC side": Input parameters
- "AC side": Output parameters
- "GF Interface": Parameters relating to the insulation of the PV generator
- "MPPT[V]": Automatic scanning of MPPT ON/OFF, SP1-SP2 voltage values at which the inverter works if MPPT is at OFF.
- "Fans": Information about the fans in the inverter (revolutions per minute rpm)
- "Temperature [°C]": Internal temperature of the Inverter
- "Inner Clock": Inverter Date and Time
- Indicators relating to the general state of the inverter (status), to the 485 (RS 485) serial communication and power derating
- Statistical data relating to the production of energy by the inverter




The indicators can assume three different states:

- Green LED indicates correct operation
- Red LED indicates alarm
- Orange LED indicates warning

The "GF Interface" field can be expanded to display more information about the Leakage current and the ground insulation resistance measured by each of the inverter's calculation devices.

The "MPPT [V]" field, if ON (default), permits automatic scanning of the maximum power point. If OFF, only scans after a reconnection to the grid. SP1-SP2 indicate the inverter working input voltages if the MPPT point search function is disabled.



The "temperature [°C]" field can be expanded to display more information about the temperatures measured by the various temperature sensors in the inverter:

Temperature [°C]			
21.7	T Booster	23.5	T Inverter R
23.7	T Inverter (max)	23.3	T Inverter S
28.1	T Ambient	23.7	T Inverter T

3 - Displaying of the instantaneous monitoring data of the CORE centralized inverter CORE (Power Converter).

Unit State

Run	Global
Run	Inverter
No Alarm	Alarm
Supervisor Alive CNT	
Inverter Alive CNT	

DC side

765.89	V_IN [V]
358.65	I_IN [A]
273622.90	P_IN [W]
Vbulk [V]	
382.8	VB+
383.1	VB-

Inner clock

04/12/2015 - 09:29:21

UNIT ● **COMM.** ●

- User request derating
- Grid OF Derating
- Grid AVG OV Derating
- Anti Islanding Derating
- Grid OC Derating
- OTH Derating
- Input OV Derating
- Temp VS Vin Derating

M String Cell

Energy [kWh]

E0: Production

5628	TOT
5628	PAR
93	TOD
1205	WEK
939	MON
5630	YEA

AC side

286162	Pac [W]	OPEN	AC Contactor		
-7844	Qac [VAR]				
50.00	Fac R	315.6	V-T-R	516.53	I-R 25.81 Icap_R
50.02	Fac S	317.9	V-R-S	516.81	I-S 26.01 Icap_S
50.01	Fac T	319.5	V-S-T	510.25	I-T 25.53 Icap_T

Fans

4058	Fan IGBT1 [rpm]	1403	Fan DC1 [rpm]
4064	Fan IGBT2 [rpm]	1423	Fan DC2 [rpm]
3907	Fan IGBT3 [rpm]	1411	Fan DC3 [rpm]
4011	Fan IGBT4 [rpm]	1416	Fan DC4 [rpm]
3935	Fan IGBT5 [rpm]	0	Fan DC5 [rpm]
4028	Fan IGBT6 [rpm]	0	Fan DC6 [rpm]
0	Fan CAP R [rpm]	0	Fan CAP S [rpm]
0	Fan CAP T [rpm]		

Temp [°C]

25.7	Pow Supply	52.4	IGBT 1 R	53.0	IGBT 2 R
23.7	Ambient	51.2	IGBT 1 S	54.2	IGBT 2 S
41.3	Reactor1	50.8	IGBT 1 T	53.0	IGBT 2 T
26.4	Reactor2	26.2	Board	23.0	DSP

The data available relates to:

- "Unit State": General state of the conversion box
- "DC side": Box input parameters
- "AC side": Box output parameters
- "Fans": Parameters relating to the operating state of the fans (revolutions per minute: rpm)
- "Temperature [°C]": Internal temperature of the Inverter
- "Inner Clock": Inverter Date and Time
- Indicators relating to the general state of the inverter (status), to the 485 (RS 485) serial communication and power derating
- Statistical data relating to the production of energy by the inverter

The indicators can assume three different states:


- Green LED indicates correct operation
- Red LED indicates alarm
- Orange LED indicates warning

"Partner Devices" tab

Displays the tree structure of the logic and/or signal acquisition boards present in the inverter.



Used to associate a new component of the inverter, either in the event of replacement of an auxiliary part or in the event of the addition of an expansion board.




Select one of the boards present in the tree structure for more information.



"Partner ID" tab (display board)

(Depending on the inverter model, the tab may differ or may not be present, refer to the product manual)


Displays the display identity card



"Partner ID" tab (Communication board)


(Depending on the inverter model, the tab may differ or may not be present, refer to the product manual)

Displays the communication board identity card



"States" tab (Communication board)

Displays the operating state of the devices monitored by the board.



In particular in the Global section:

PMU presence indicates the presence of the PMU device

OTH indicates the state of the temperature protection

In the SPD monitoring section:

The state of the dischargers (SPD) is indicated, DC side and AC side.

In the SPD settings section:

The monitoring of the DC and AC dischargers is enabled.

Arc fault settings section:

The Arc fault protection is enabled.

The indicators can assume three different states (colors):

- green correct operation
- red damage to the part indicated
- gray functionality not checked

"Measurements" tab (Communication board)


Displays the values of the analogic and environmental inputs acquired

MEASURE	Unit	Value
PT100 (ana.)	Ohm	155.189
PT1000 (ana.)	Ohm	1551.891
ANA 1 (ana.)	mA	0.000
ANA 2 (ana.)	mA	0.000
PT100 (conv.)	°C	144.370
PT1000 (conv.)	°C	144.370
ANA 1 (conv.)	W/mq	0.000
ANA 2 (conv.)	W/mq	0.000
NTC (ana.)	V	2.690
NTC (conv.)	°C	31.000

The number of measurement values acquired varies according to the settings applied on the "Analog Input Settings" tab as, if the reading of the analogic sensors is enabled the value of the measurement converted to the actual value is displayed

"Analog Input Settings" tab (Communication board)

Used to enable/disable the analogic inputs connected to the inverter in addition to the possibility of applying the settings relating to the AN1 and AN2 analogic inputs. For each of the analogic sensors it is possible to set the Gain, the offset and the unit of measurement. The data will be saved in the inverter on confirming by pressing the SET button.



Below are indicated the values to be set for the ABB sensors that can be connected to the inverter:


	Type	Gain	Offset	U.of.M.
PVI-AEC-IRR	Radiation sensor	120	0	W/m ²
PVI-AEC-IRR-T	Radiation sensor with integrated cell temp. sensor	Radiation: 120 Cell temp.: 10.869	Radiation: 0 Cell temp.: -20	Radiation: W/m ² Cell temp.: °C
PVI-AEC-RAD-13TC	Radiation sensor	130	0	W/m ²
PVI-AEC-RAD-13-TC-T	Radiation sensor with integrated cell temp. sensor	Radiation: 130 Cell temp.: 11.507	Radiation: 0 Cell temp.: -26.1	Radiation: W/m ² Cell temp.: °C
PVI-AEC-CONV-T100	PT100/0...10V converter	15	-50	°C at 0...10V
PVI-AEC-T1000-INTEGR	Ambient temperature sensor with integrated converter	10	-50	°C
PVI-AEC-WIND-COMPACT	Wind speed sensor	5	0	m/s
PVI-AEC-PYR-1300	Pyranometer (0...1300W/m ²)	65	0	W/m ²
PVI-AEC-T100-ADH	Module temperature sensor (back cell) PT100 adhesive	N/A	N/A	N/A
PVI-AEC-T1000-BOX	Ambient temperature sensor PT1000	N/A	N/A	N/A



"Partner ID" tab (Fuse Control Board)

(Depending on the inverter model, the tab may differ or may not be present, refer to the product manual)


Displays the board's identity card




"States" tab (Fuse Control Board)

Displays the operating state of the parameters monitored:

- Image relating to the TRIO-20.0-TL



- Image relating to the TRIO-50.0-TL



The "Global" subfield indicates the general state of the protections.

The "Strings" subfield indicates the string fuses state indicators

The "Currents" subfield relating to the TRIO-20.0/27.6-TL-OUTD indicates the state indicators for the individual string currents which in the event of an imbalance change color to red. The monitoring and displaying of the state of the string fuses can be enabled on the "Strings Setting" tab (fuse control board).

The "Current/Voltage" subfield relating to the TRIO-50.0-TL-OUTD indicates the monitoring of the voltage and of the input currents. In particular the protections relating to the currents are monitored in groups. Each group consists of 3 or 4 strings, depending on the DC wiring box model installed on the inverter (12 or 16 inputs).

The indicators can assume 4 different states (colors)

- green correct operation
- red alarm active
- orange warning active
- gray function not enabled (OFF position on the "strings settings" tab)

"Measures" tab (Fuse Control Board)

Displays the values of the parameters relating to the strings connected as input (image relating to the TRIO-50.0-TL)

Name	Value	Measure Unit
STRNG_VOLTAGE_1A	817.005	V
STRNG_VOLTAGE_1B	816.655	V
STRNG_VOLTAGE_1C	817.005	V
STRNG_VOLTAGE_1D	0.927	V
STRNG_VOLTAGE_2A	59.393	V
STRNG_VOLTAGE_2B	59.393	V
STRNG_VOLTAGE_2C	60.094	V
STRNG_VOLTAGE_2D	0.577	V
STRNG_VOLTAGE_3A	819.105	V
STRNG_VOLTAGE_3B	81.844	V
STRNG_VOLTAGE_3C	62.544	V
STRNG_VOLTAGE_3D	0.927	V
STRNG_VOLTAGE_4A	57.993	V
STRNG_VOLTAGE_4B	59.393	V
STRNG_VOLTAGE_4C	60.794	V
STRNG_VOLTAGE_4D	0.577	V
STRNG_VOLTAGE_GROUP1	811.753	V
GROUP_CURRENT_1	16.612	A
GROUP_CURRENT_2	0.179	A
GROUP_CURRENT_3	5.525	A
GROUP_CURRENT_4	0.052	A

"Parameters" tab (Fuse Control Board)



Displays the parameters set via "Global settings" and "String Settings" (Fuse control board) during the installation phase.

It is possible to extend the configuration of the strings and protections to all or some of the inverters connected to the same 485 line.

Name	Value	Measure Unit
CURRENT_CHECK_FLAG	15	--
CURRENT_WEIGHT_1	1	--
CURRENT_WEIGHT_2	1	--
CURRENT_WEIGHT_3	1	--
CURRENT_WEIGHT_4	1	--
CURRENT_WEIGHT_5	0	--
CURRENT_WEIGHT_6	0	--
CURRENT_WEIGHT_7	0	--
CURRENT_WEIGHT_8	1	--
CURRENT_WEIGHT_9	1	--
CURRENT_WEIGHT_10	0	--
CURRENT_WEIGHT_11	0	--
CURRENT_WEIGHT_12	1	--
CURRENT_WEIGHT_13	0	--
CURRENT_WEIGHT_14	0	--
CURRENT_WEIGHT_15	0	--
CURRENT_WEIGHT_16	1	--
MIN_CURRENT_CHECK_TH	4.000	A
OVER_VOLTAGE_TH	1000.000	V
MAX_CURRENT_DEVIATION	12.000	A
OVER_CURRENT_TH	12.000	A
MAX CURRENT DEVIATION TRIP TIME	30	s

Write this configuration on all connected inverters

Write this configuration choosing inverter by serial number and RS485 address

Pressing the "Write this configuration on all connected inverters" button extends to all the inverters that make up the system, connected to the same 485 serial.

Pressing the "Write this connection choosing inverter by s/n and RS485 address" button extends the configuration only to the inverters required in 485 address order.

"Global Settings" tab (Fuse Control Board)

Used to apply the settings relating to the check of the input currents. Depending on the type of inverter, different screens will be displayed:

1. Screen relating to the TRIO-20.0/27.6-TL-OUTD

Unbalanced currents check threshold

- Absolute value of enabling of the check of imbalance of the currents (one for each of the two input MPPTs). The default value is 2A.

Overcurrent threshold

- Overcurrent threshold (one for each of the two input MPPTs). The default value is 10A.

Unbalanced currents check trip time

- Duration for which the current imbalance must be present in order for the alarm to be generated. It is recommended that this parameter is set to more than 900 seconds to avoid false alarms.

Partner ID	States	Measures	Global Settings	Strings Settings
2.000	0.000	Unbalanced currents check threshold [A] - CH. 1		
10.000	0.000	Overcurrent threshold [A] - CH. 1		
2.000	0.000	Unbalanced currents check threshold [A] - CH. 2		
10.000	0.000	Overcurrent threshold [A] - CH. 2		
600	0	Unbalanced currents check trip-time [s]		

SET

DC strings self-test

→ Test enabled
→ Test disabled

By clicking on "SET" the values are set in the fuse control board of the inverter selected.

The "DC strings self-test" function is used to enable the function for checking the polarity of the string voltages during the first start-up of the inverter.

2. Screen relating to the TRIO-50.0-TL-OUTD

Minimum currents check threshold

- Absolute value of enabling of the check of imbalance of the currents (one for each group of 3/4 input strings). The default value is 2A.

Overcurrent threshold

- Overcurrent threshold (one for each group of input strings). The default value is 12A.

Max currents deviation

- Maximum imbalance permitted before the alarm is triggered. The default value is 2A.

Max currents deviation trip time

- Duration for which the current imbalance must be present in order for the alarm to be generated. The default value is 300 seconds.

Overvoltage threshold

- Overvoltage threshold (one for each group of input strings). The default value is 1000V.

Partner ID	States	Measures	Parameters	Global Settings	Strings Settings
4.000	4.000	Minimum current check threshold [A\string]			
12.000	12.000	Overcurrent threshold [A\string]			
12.000	12.000	Max current deviation [A\string]			
30	30	Max current deviation trip-time [s]			
1000.000	1000.000	Overvoltage threshold [V]			

SET

By clicking on "SET" the values are set in the fuse control board of the inverter selected.

"Strings setting" tab (Fuse Control Board)

Used to apply the monitoring settings for each string.

Image relating to the TRIO-20.0/27.6-TL:

Partner ID | States | Measures | Global Settings | Strings Settings

String ID	States	Measures	Global Settings	Strings Settings
1A	ON/OFF	WEIGHT 1.000	SET	Current check enable ON/OFF
1B	ON/OFF	WEIGHT 1.000	SET	Current check enable ON/OFF
1C	ON/OFF			
1D	ON/OFF			
1E	ON/OFF			
2A	ON/OFF	WEIGHT 1.000	SET	Current check enable ON/OFF, TOLERANCE 20.000
2B	ON/OFF	WEIGHT 1.000	SET	Current check enable ON/OFF, TOLERANCE 20.000
2C	ON/OFF	WEIGHT 1.000	SET	Current check enable ON/OFF, TOLERANCE 20.000
2D	ON/OFF			
2E	ON/OFF			

Represents the enabling of the string currents check and relative generation of the unbalanced current alarm
 ON = String current check active
 OFF = String current check inactive

Represents the enabling of the "string presence" check
 ON = Input string present
 OFF = Input string not present


In particular it permits:

1. Enabling of the check of the presence of each of the input strings connected.
 The check of the presence of the individual input string is enabled by switching the selector from the OFF position to ON (by clicking on the selector)
2. Enabling of the check of the current imbalance on each input string and setting of its current reading weight (weight = N° of strings connected in parallel to the individual string input) and tolerance (maximum imbalance permitted before the alarm is triggered) expressed as a percentage.
 The check of the string current imbalance is enabled by switching the selector from the OFF position to ON (by clicking on the selector)

By clicking on "SET" the values are set in the fuse control board of the inverter selected.

The state of enabling of the presence of each string is displayed on the "States" tab (fuse control board) together with the state of the relative fuse.

Image relating to the TRIO-50.0-TL:




In particular it permits:

1. Enabling of the check of the presence of each of the input strings connected.
The check of the presence of the individual input string is enabled by switching the selector from the OFF position to ON (by clicking on the selector).
When at least one string is activated, the current imbalance check is enabled (default active).
2. Setting of the current reading weight (weight = n° of strings connected in parallel to the individual input).
The tolerance (maximum imbalance permitted before the alarm is triggered) can be set from the "Global settings - Max Currents Deviation" tab (default 2A).


"Partner ID" tab (wi-fi board)

(Depending on the inverter model, the tab may differ or may not be present, refer to the product manual)
 Displays the board's identity card




"Partner ID" tab (Ethernet board)

(Depending on the inverter model, the tab may differ or may not be present, refer to the product manual)
 Displays the board's identity card




"Partner ID" tab (PMU board)

(Depending on the inverter model, the tab may differ or may not be present, refer to the product manual)
 Displays the board's identity card




"States" tab (PMU board)

Displays the operating state of the digital inputs



"Measures" tab (PMU board)

Displays the values of the parameters relating to the analogic and environmental inputs. The parameters read will have a meaningful value if correctly enabled and configured on the "Analogic input settings" tab.



"Analogic inputs settings" (PMU board)

Displays the settings relating to the analogic inputs

Used to enable/disable the analogic inputs connected to the inverter in addition to the possibility of applying the settings relating to the AN1/AN2/AN3/AN4 analogic inputs. For each of the analogic sensors it is possible to set the GAIN, the offset and the unit of measurement. The data will be saved on confirming by pressing the SET button.


The PTC function permits enabling/disabling of the input in PT100 or PT1000 mode according to the type of sensor connected.

Below are indicated the values to be set for the ABB sensors connected to the inverter:

	Type	Gain	Offset	U.of.M.
PVI-AEC-IRR	Radiation sensor	120	0	W/m ²
PVI-AEC-IRR-T	Radiation sensor with integrated cell temp. sensor	Radiation: 120 Cell temp.: 10.869	Radiation: 0 Cell temp.: -20	Radiation: W/m ² Cell temp.: °C
PVI-AEC-RAD-13TC	Radiation sensor	130	0	W/m ²
PVI-AEC-RAD-13-TC-T	Radiation sensor with integrated cell temp. sensor	Radiation: 130 Cell temp.: 11.507	Radiation: 0 Cell temp.: -26.1	Radiation: W/m ² Cell temp.: °C
PVI-AEC-CONV-T100	PT100/0...10V converter	15	-50	°C at 0...10V
PVI-AEC-T1000-INTEGR	Ambient temperature sensor with integrated converter	10	-50	°C
PVI-AEC-WIND-COMPACT	Wind speed sensor	5	0	m/s
PVI-AEC-PYR-1300	Pyranometer (0...1300W/m ²)	65	0	W/m ²
PVI-AEC-T100-ADH	Module temperature sensor (back cell) PT100 adhesive	N/A	N/A	N/A
PVI-AEC-T1000-BOX	Ambient temperature sensor PT1000	N/A	N/A	N/A


"Aux RS485" tab (PMU board)

Displaying and setting relating to the 485 communication protocol and relative baud rate



"PMU" tab (PMU board)

Displaying and setting relating to the active and reactive power management mode.



The following table indicates the active power limitation/reactive power management modes that can be selected via the PMU board:

Name on the display	Operation	Inputs
Mode 0	No PMU function selected	-
Mode 1	Reduction of the active power in 4 steps	K1, K2, K3, K4
Mode 2	Reduction of the active power by means of analogic inputs	AN3
Mode 3	Reduction of the active power in 4 steps	K1, K2, K3, K4
	Check of the reactive power by means of analogic inputs	AN4 (Type 2)
Mode 4	Reduction of the active power by means of analogic inputs	AN3
	Check of the reactive power by means of analogic inputs	AN4 (Type 2)
Mode 5	Reduction of the active power in 4 steps	K1, K2, K3, K4
	Check of the reactive power by means of analogic inputs	AN4 (Type 4)
Mode 6	Reduction of the active power by means of analogic inputs	AN3
	Check of the reactive power by means of analogic inputs	AN4 (Type 4)
Mode 7	Check of the reactive power by means of analogic inputs	AN4 (Type 2)
Mode 8	Check of the reactive power by means of analogic inputs	AN4 (Type 4)
Mode 9	Reduction of the active power in 11 steps	K1, K2, K3, K4
	Check of the reactive power by means of analogic inputs	AN4 (Type 4)
Mode 10	Reduction of the active power by means of analogic inputs	AN3
	Check of the reactive power by means of analogic inputs	AN4 (Type 4)



- Check of the active power by means of digital inputs in 4 steps
This type of check is used in operating modes 1, 3, 5.

The digital inputs for limiting the active power are K1, K2, K3 and K4

K1	K2	K3	K4	Maximum active power as % of the nominal power of the inverter
Closed	Open	Open	Open	100
Open	Closed	Open	Open	60
Open	Open	Closed	Open	30
Open	Open	Open	Closed	0

- Check of the active power by means of digital inputs in 11 steps.
This type of check is used in operating mode 9.

The digital inputs for limiting the active power are K1, K2, K3 and K4

K1	K2	K3	K4	Maximum active power as % of the nominal power of the inverter
Open	Closed	Open	Closed	100
Closed	Open	Open	Closed	90
Open	Open	Open	Closed	80
Closed	Closed	Closed	Open	70
Open	Closed	Closed	Open	60
Closed	Open	Closed	Open	50
Open	Open	Closed	Open	40
Closed	Closed	Open	Open	30
Open	Closed	Open	Open	20
Closed	Open	Open	Open	15
Closed	Closed	Open	Closed	0


- Check of the active power by means of an analogic input (AN3).

This type of check is used in operating modes 2, 4, 6, 10.

The analogic input for the limitation of the active power is AN3.

With this type of check the output active power can be managed dynamically based on the value of the analogic input signal. This signal may be a current (4...20mA) or a voltage (0...10V).

The limitation of the nominal output power is applied to the inverter in accordance with the graphs below (on the left → input current; on the right → input voltage):



- Check of the reactive power by means of an analogic input (AN4).

This type of check is used in operating modes 3, 4, 5, 6, 7, 8, 9 and 10.

The management modes have different behaviors described below.

The analogic input for checking the reactive power is AN4.

With this type of check the reactive power can be managed dynamically based on the value of the analogic input signal. This signal may be a current (4...20mA) or a voltage (0...10V).


There are 2 reactive power management modes:

Type 2 → $\tan(\phi)$ fixed based on the instantaneous output power


Type 4 → $\cos(\phi)$ fixed based on the instantaneous output power

The management of the reactive power is applied to the inverter in accordance with the graphs below (on the left → input current; on the right → input voltage):

Operating mode Type 2




Operating mode Type 4



"Data logger" tab


Displays the values of the input and output parameters detected by their inverter:

- Data logger setting: Used to set the recording period (minimum time 2 seconds) and ticking "Stop after N samples" sets the number of samples.
- Data logger Enable: Enables/disables the recording of the sample.
- File setting: Text mode for saving the logger data.
- Configuration setting: used to upload a customized list of parameters (for service use only).




"Event log" tab

Used to download the alarms and warnings logs and the configuration of the internal variables.



All of the settings that can be applied in this section can be extended to all of the inverters connected to the RS485 bus by positioning the selector on "Apply access log on ALL connected units". The default position applies the setting only to the inverter selected in the tree structure of the system.

By ticking the "continue to read log also on communication errors" field, the scan of the 485 line continues even if communication errors on the part of one or more inverters are detected.



"Alarms & warnings" tab

Used to download the Alarms and Warnings logs.



By means of the two radio buttons "ALARM Log" and "WARNING Log", the type of events to be downloaded can be selected. Then, downloading is by means of the "Read LOG" button.



The "Save to XML" button can be used to export the log as an xml file.




"Variables" tab

Used to download the variables that have changed compared to the default configuration of the inverter.

Unit SN	Time-Stamp	Parameter ID	Parameter Descriptor	Value	M. U.	Change Source	Change PSW
150515	10/20/2015 14:1...	(5505, P, UInt32, Device: POW_Super...	DIGITAL OUTPUT 0 - MODE	8	---	N/A <45>	-NULL-
150515	10/16/2015 11:2...	(9732, P, UInt32, Device: POW_Super...	GOGO RELAY - MINIMUM TIME RELAYO...	901	sec	N/A <45>	-NULL-
150515	10/16/2015 11:2...	(9731, P, UInt32, Device: POW_Super...	GOGO RELAY - MINIMUM TIME RELAY ON	112	sec	N/A <45>	-NULL-

"Setup" tab Available only with the INSTALLER access level

Permits advanced configuration of the inverter (by entering the login details obtained after registering on the site <https://registration.abbsolarinverters.com/> on the "Configuration > Setup area Access" menu).




Access log on ALL connected units
 Access log only on the selected unit Continue to read log also on communication errors

All of the settings that can be applied in this section can be extended to all of the inverters connected to the RS485 bus by positioning the selector on "Access log on ALL connected units". The default position applies the setting only to the inverter selected in the tree structure of the system. By ticking the "Continue to read log also on communication errors" field, the scan of the 485 line continues even if communication errors on the part of one or more inverters are detected.

All of the parameters that can be set in this section of Aurora Manager LITE are described in the "Structure of the work area" in the Specifications section

"DC side" tab:

Used to configure the parameters Vstart (Start input voltage), UV protection time (Low voltage protection time) and MPPT.



DC side | AC side | Special functions | Ground fault interface | Clock | Digital Input | Digital Output | Serial Links | Night Startup Mode

Start input voltage

ACTUAL	NEW	
420.000	420.000	Vstart 1 - Minimum channel 1 voltage for grid connection [V]

Under voltage protection time

ACTUAL	NEW	
60000	60000	UV protection time - Timeout for grid disconnection if (Vin < 70% Vstart) [ms]

MPPT

ACTUAL	NEW	
900000	900000	Multiple max. scan period [ms]
5.000	5.000	MPPT noise amplitude [V]

Multiple max. scan ENABLED
 Multiple max. scan DISABLED

SET

In particular it permits the application of the following settings:

- Minimum channel voltage for grid connection: Activation voltage (Vstart) for every input channel.
- Timeout for grid disconnection (UV protection time): Time during which the inverter draws power from the grid in the presence of an input UnderVoltage. Once the time set has elapsed, the inverter disconnects from the grid.
- Enable/disable the "Multiple Max scan" (MPPT scan) function and setting of the time interval between one scan and the next "Multiple max scan period".
- MPPT noise amplitude: used to change the noise amplitude set by the inverter for the maximum power point search.


"AC side" tab:

Used to configure the parameters which permit connection to the grid and the relative protections and/or power limits.

In particular there are 6 sections (tabs) which permit:

Grid connection

Used to set the grid parameters that must be observed during the connection phase:



Apply setup changes to ALL connected units
Apply setup changes only to the selected unit

side | AC side | Special functions | Ground fault interface | Clock | Digital Input | Digital Output | Serial Links | Night Startup Mode

Grid connection | Grid protection | High frequency derating | V Grid rise suppression (Max AVG V Grid) | Anti Islanding

Voltage and frequency ranges for grid connection

ACTUAL	NEW	
253.000	253.000	Maximum grid voltage for connection [V]
195.500	195.500	Minimum grid voltage for connection [V]
50.100	50.100	Maximum grid frequency for connection [Hz]
49.900	49.900	Minimum grid frequency for connection [Hz]
30	30	Time for V/F check before connection or after generic fault [s]
300	300	Time for V/F check after grid fault [s]

Slow power ramp after grid connection

Slow ramp ENABLED 20.000 20.000 Ramp Slope %Pn/min
 Slow ramp DISABLED 0.200 0.200 Ramp Slope Fault %Pn/min

SET

In particular it permits the application of the following settings:

- Max grid voltage for connection. Maximum Voltage threshold for connection to the grid.
- Min grid voltage for connection. Minimum Voltage threshold for connection to the grid.
- Max grid frequency for connection. Maximum Frequency threshold for connection to the grid.
- Min grid frequency for connection. Minimum Frequency threshold for connection to the grid.
- Time for V/F check before connection or after generic fault. Grid check interval before connection or after a generic fault. Can be set from 0 ... 3600s.
- Time for V/F check after grid fault. Grid check interval before connection after a grid fault. Can be set from 0 ... 3600s.
- Slow ramp enable/disable. Enabling of the function for gradual delivery of the power after connection to the grid.
- Ramp slope [%Pn/min]. Slope of the ramp for admission of power to the grid indicated as a percentage of the nominal power per minute.
- Ramp Slope Fault [%Pn/min]. Slope of the ramp for admission of power to the grid after a disconnection caused by a fault, indicated as a percentage of the nominal power per minute.

Grid protection

Used to enable/disable and/or set the limit values and intervention times for the protections relating to the grid voltage:

EN	DIS	ACTUAL	NEW		ACTUAL	NEW	TRIP TIME [ms]
<input type="checkbox"/>	<input type="checkbox"/>	287.500	287.500	U>> Maximum grid voltage [V]	50	50	Trips time [ms]
<input type="checkbox"/>	<input type="checkbox"/>	264.500	264.500	U> Maximum grid voltage [V]	100	100	Trips time [ms]
<input type="checkbox"/>	<input type="checkbox"/>	184.000	184.000	U< Minimum grid voltage [V]	1000	1000	Trips time [ms]
<input type="checkbox"/>	<input type="checkbox"/>	69.000	69.000	U<< Minimum grid voltage [V]	300	300	Trips time [ms]
<input type="checkbox"/>	<input type="checkbox"/>	10.000	10.000	U<<< Minimum grid voltage [V]	300	300	Trips time [ms]
<input type="checkbox"/>	<input type="checkbox"/>	65.000	65.000	F>> Maximum grid frequency [Hz]	100	100	Trips time [ms]
<input type="checkbox"/>	<input type="checkbox"/>	51.500	51.500	F> Maximum grid frequency [Hz]	100	100	Trips time [ms]
<input type="checkbox"/>	<input type="checkbox"/>	47.500	47.500	F< Minimum grid frequency [Hz]	100	100	Trips time [ms]
<input type="checkbox"/>	<input type="checkbox"/>	45.000	45.000	F<< Minimum grid frequency [Hz]	100	100	Trips time [ms]
		2.000	2.000	K LVVRT			


In particular it permits the application of the following settings:

- U>> Max grid voltage. Grid over-voltage (OV) threshold (extended range). Can be set from U_{nom} to $U_{nom} \times 1.3$
- U> Max grid voltage. Grid over-voltage (OV) threshold. Can be set from U_{nom} to $U_{nom} \times 1.3$
- U< Min grid voltage. Grid under-voltage (UV) threshold. Can be set from 10V to U_{nom} .
- U<< Min grid voltage. Grid under-voltage (UV) threshold (extended range). Can be set from 10V to U_{nom} .
- U<<< Min grid voltage. Third grid under-voltage (UV) threshold. Can be set from 10V to U_{nom} (active for UL Rule 21-Hawaii grid).
- F>> Max grid frequency. Grid over-frequency (OF) threshold (extended range). Can be set from F_{nom} to $F_{nom} + 5\text{Hz}$.
- F> Max grid frequency. Grid over-frequency (OF) threshold. Can be set from F_{nom} to $F_{nom} + 5\text{Hz}$.
- F< Min grid frequency. Grid under-frequency (UF) threshold. Can be set from $F_{nom} - 5\text{Hz}$ to F_{nom} .
- F<< Min grid frequency. Grid under-frequency (UF) threshold (extended range). Can be set from $F_{nom} - 5\text{Hz}$ to F_{nom} .
- K LVVRT low voltage ride-through coefficient. Regulates the reactive current that can be injected into the grid during a grid dip.


High frequency derating

Used to set the parameters relating to the power derating due to a high grid frequency:

- Image relating to the TRIO-20.0-TL-OUTD



- Image relating to the TRIO-50.0-TL-OUTD




In particular it permits the application of the following settings:

- Frequency threshold derating start/stop: Setting of the frequency threshold at which the inverter starts/stops the power derating.
- Power/frequency slew rate: Setting of the speed of reduction of the power value due to the derating.
- Restore time after OF derating: Time necessary to restore normal operation of the inverter after the frequency has returned to within the range.
- Derating Mode: Selection of the power derating mode in the event of a grid over-frequency. The modes that can be selected, defined by the grid standard set, are: Derating Disabled; BDEW derating; VDE-AR-N derating; CEI derating.
- Intentional delay time: setting of the intentional delay for reduction of the active power in accordance with the grid frequency.
- Release ramp EN/DIS: enabling/disabling of the ramp for derating due to a high grid frequency.

Vgrid rise suppression (Max AVG grid)

Used to enable/disable and/or set the parameters relating to the over-voltage protection of the average grid voltage value. It is also possible to enable the derating that could prevent disconnection from the grid (the intervention of the protection) by reducing the active power.




In particular it permits the application of the following settings:

- Protection EN/DIS: Enabling/Disabling of the U> protection threshold (10Min).
- Derating EN/DIS: Enabling of the power derating mode due to high values of the average of the readings taken on the grid voltage.
- Protection threshold: Grid over-voltage (OV) threshold (average measurement of the grid voltage value). Can be set from $U_{nom} \times 1.3$

Anti Islanding

Used to enable/disable the parameters relating to the anti islanding protection for disconnection of the inverters in the event of loss of the grid, or this protection intervenes to prevent the inverter from working as an island in the event of loss of the grid.


- Image of the TRIO-20.0/27.6-TL-OUTD



In particular it permits the application of the following settings:

- Active Anti islanding reactive pulse: enables/disables the anti islanding protection. To check the presence of the grid, the inverter generates a frequency variation by means of a reactive power at regular intervals. If the inverter is connected to the grid, the reactive power does not generate any variation in the frequency.
- Active Anti islanding frequency drift: enables/disables the anti islanding protection for three-phase inverters. To check the presence of the grid the inverter generates a frequency chirp at regular intervals. If the inverter is connected to the grid, the chirp does not generate any variation in the grid frequency.
- Passive Anti islanding: enables/disables the passive anti islanding protection. The inverter does not admit chirps to the grid but passively checks the grid parameters. In particular, the protection will be configured with time (expressed in seconds) and grid frequency offset (expressed in degrees) limits.

- Image of the TRIO-50.0-TL-OUTD



In particular it permits the application of the following settings:

- Active Anti islanding Disabled: disables the active anti islanding protection.
- Active Anti islanding reactive pulse: enables/disables the anti islanding protection. To check the presence of the grid, the inverter generates a frequency variation by means of a reactive power at regular intervals. If the inverter is connected to the grid, the reactive power does not generate any variation in the frequency.
- Active Anti islanding frequency shift: enables/disables the anti islanding protection for single-phase inverters. To check the presence of the grid the inverter generates a frequency chirp at regular intervals. If the inverter is connected to the grid, the chirp does not generate any variation in the grid frequency.
- Active Anti islanding frequency drift: enables/disables the anti islanding protection for three-phase inverters. To check the presence of the grid the inverter generates a frequency chirp at regular intervals. If the inverter is connected to the grid, the chirp does not generate any variation in the grid frequency.
- Passive Anti islanding Disabled: disables the passive anti islanding protection.
- F.derivate: enables/disables the passive anti islanding protection. The inverter does not admit chirps to the grid but passively checks the variations in the grid frequency within the time limits which can be set (expressed in seconds).

LVRT/HVRT-LFRT/HFRT

(Depending on the inverter model, the tab may differ or may not be present, refer to the product manual)

Used to enable/disable and set the value of the coefficient which regulates the reactive power admitted to the grid during a grid dip.



"Special Function" tab

- TRIO-20.0/27.6-TL-OUTD

Permits the application of the following settings:

- Remote ON/OFF: Enabling/disabling of the function for switching the inverter off/on remotely.
- Remote ON/OFF (ext command): Switches the inverter off (OFF command) and on (ON command) via software.
- Reset mode: Inverter restart mode after an alarm relating to the grid parameters. The restart can be set to manual or automatic.
- Radio Frequency Injection: Setting of a frequency value for any PLC signals which the inverter must not identify as errors relating to the grid parameters. If reactive power is admitted to the grid, the PLC signals which fall within the range set will not be reduced.
- Digital alarm contact: Setting of the operating mode of the alarm contact (further details relating to the operating modes can be found in the product manual, "Operation" section, "Settings menu" paragraph).



- TRIO-50.0-TL-OUTD

Used to switch the inverter off/on via software:

"Ground Fault Interface" tab

Used to set the parameters relating to the measurement of the photovoltaic generator insulation resistance:

Riso check		
ACTUAL	NEW	Minimum Riso [ohm]
100000.000	100000.000	20000
20000	20000	Minimum time for Riso check [ms]

Grounding kit		
Protection ENABLED	ACTUAL	NEW
Protection DISABLED	200.000	200.000
		Maximum Vgnd [V]

SET

In particular it permits the application of the following settings:

- Minimum Riso: Minimum value of the insulation resistance (Riso) which permits connection of the inverter to the grid.
- Minimum time for Riso check: Duration of measurement of the insulation resistance before connection.

Only for TRIO-50.0-TL-OUTD:

- Enables the grounding kit function (Negative ground) and sets the maximum voltage between the negative pole and the ground.




"Clock" tab

Used to set the inverter's internal date and time.

The inverter date and time can be aligned with those of the PC "Use PC time" or set manually "Select time".


The data will be saved in the inverter on confirming by pressing the "SET" button.



"Digital input" tab

(Depending on the inverter model, the tab may differ or may not be present, refer to the product manual)

Used to enable the inverter's digital input signals.



User Inputs:


Used to set the digital inputs of the pull-down menu:

- Remote off: enables the remote switching off of the inverter.
- Stand_Alone: enables islanding, in the event of a black-out, using the optional dedicated board. Further details relating to the operating mode can be found in the product manual, "Installation" section, "Stand alone output connection enabling" paragraph.
- Input3/4/5: not used.

"Digital output" tab

(Depending on the inverter model, the tab may differ or may not be present, refer to the product manual)

Used to enable the inverter's digital output signals.




In particular it permits the enabling of:

- OUT Slot: permits the selection of one of the two inverter digital output signals [AUX-ALARM]
- Slot setting: permits setting of the digital output functions of the pull-down menu:
 - Production: the relay is activated when the inverter connects to the grid and returns to the rest position when the inverter disconnects from the grid.
 - Alarm_All_no_latch: the relay is activated each time a grid parameters outside tolerances error or warning arises and returns to the rest position when the error or warning ceases.
 - Alarm_configurable_no_latch: the relay is activated each time an error or warning among those selected from the list on the pull-down menu arises and returns to the rest position when the error or warning ceases.
 - Crepuscular: the relay is activated as soon as the input voltage exceeds the activation voltage and returns to the rest position when the input voltage falls below 70% of the V start set.
 - Alarm_all_latch: the relay is activated each time an error or warning arises and returns to the rest position when the inverter returns to normal operation and has reconnected to the grid.
 - Alarm_configurable_latch: the relay is activated each time an error or warning among those selected from the list on the pull-down menu arises and returns to the rest position when the inverter returns to normal operation and has reconnected to the grid.
 - Alarm_configurable_latchmatrix: the relay is activated each time an error or warning among those selected from the list on the pull-down menu arises and the "latch" or "no latch" mode can be set for each individual indication.

"Serial Link" tab

Used to change the parameters of the serial communication.




In particular it permits changing in the two 485 inputs of the communication protocol and the baud rate.

(Parity checks that the datum received is correct).

"Night Startup Mode" tab

(Depending on the inverter model, the tab may differ or may not be present, refer to the product manual)

Used to enable night-time operation of the logic functions of the inverter.



In particular, enabling this command keeps the functions of the logic card active, which permits consultation of the display (where present) and of the communication.

- Max Vin for connection: sets the maximum input voltage permitting connection of the inverter.
- Min VBulk for connection: sets the minimum bulk voltage permitting connection of the inverter.
- Check for connection timeout: sets the waiting time for connection to the grid.

"Power Reduction" tab

This section permits regulation of the limitation of the active power that the inverter admits to the grid by setting the percentage value of the nominal power at which the limitation should take place.

Setting 100% restores the default maximum power value.

Smooth time: this is the time necessary to reach the power reduction set, with two different modes:

- Slope mode: Fixes the slope of the ramp, or the time necessary to range from 0 to 100% of the power.
- Trip-time mode: Time necessary to pass from the current output power to the new power value set.
- P limits: displaying of the limits of the inverter's active power.

All of the settings that can be applied in this section can be extended to all of the inverters connected to the RS485 bus by positioning the selector on "Apply setup changes to ALL connected units". The default position applies the setting only to the inverter selected in the tree structure of the system.

"Reactive Power Regulation" tab

This section permits regulation of the admission of reactive power delivered to the grid by the inverter.

The regulation of the reactive power is set by selecting from the pull-down menu one of the following modes:

- no regulation
- cos-phi fixed
- Q fixed
- cos-phi =f(P)
- Q(U)




All of the settings that can be applied in this section can be extended to all of the inverters connected to the RS485 bus by positioning the selector on "Apply setup changes to ALL connected units". The default position applies the setting only to the inverter selected in the tree structure of the system.

- Q limits: displaying of the limits of the inverter's reactive power.

"Select regulation mode" tab

Used to select the management mode for admission of the reactive power to the grid. Five possible selections are available.



1. No regulation


No mode for admission of reactive power to the grid is enabled. (default configuration).

2. Cos-phi fixed

Setting of the power factor to a fixed value.

Once the mode has been selected, the "Cos-phi fixed setup" field appears, permitting setting of the value of the cos-phi (over or under excited).

The selection of the mode must be confirmed using the SET button.




3. Q- fixed

Setting of Tan-phi (Q/P) to a fixed value.

Once the mode has been selected, the "Q fixed setup" field appears, permitting setting of the value of Q (over or under excited).

The selection of the mode must be confirmed using the SET button.



4. Cos-phi = f(P)

Power factor as a function of the active power supplied by the inverter.

The selection of the mode must be confirmed using the SET button. The default graph set can be displayed and modified by going to the "Cos-phi=f(P) curve setup" tab described below.

5. Q=(U)

Reactive power as a function of the grid voltage measures by the inverter.



The selection of the mode must be confirmed using the SET button. The default graph set can be displayed and modified by going to the "Q(U) curve setup" tab described below.

"Cos-phi f(P) curve setup" tab Available only with the INSTALLER access level

In this section the default graph is displayed, which can be modified by setting the values P/Pn% and relative cos-phi (under or over excited) Four points can be set which will define the trend of the graph.




Once the values have been set it will be possible to display the graph created by means of the "Check and graph my table" button.

If the graph created is that required it can be memorized in the inverter by pressing the "Write my table on device" button.

The correct writing in the inverter can be checked using the "Read table from device" button which will display the graph set correctly on the inverter.

In the event of an error or to set the default curve again, use the "Restore default curve" button.




It is possible to activate/deactivate and set the value of the activation (lock-in) and deactivation (lock-out) threshold for admission of the reactive power to the grid in accordance with the graph set previously.

"Q(U) curve set-up"

In this section the default graph is displayed, which can be modified by setting the values of the output voltage Vout and relative Q/Pn%.

Four points can be set which will define the trend of the graph.




Once the values have been set it will be possible to display the graph created by means of the "Check and graph my table" button.

If the graph created is that required it can be memorized in the inverter by pressing the "Write my table on device" button.

The correct writing in the inverter can be checked using the "Read table from device" button which will display the graph set correctly on the inverter.

In the event of an error or to set the default curve again, use the "Restore default curve" button.



It is possible to activate/deactivate and set the value of the activation (lock-in) and deactivation (lock-out) threshold for admission of the reactive power to the grid in accordance with the graph set previously.

Further information

For more information on ABB solar products and services,
visit www.abb.com/solarinverters

Contact us

www.abb.com/solarinverters